



Product Specification	
Product Code	VIT107
Collection	Alpine
Construction	Engineered
Species	European Oak
Product Type	Engineered Plank
Surface	Smooth Sanded
Finish	Oiled
Dimensions	190 x 14/3 x 1900 mm
Top Layer	3 mm - Solid European Oak
Core Layer	11 mm – 2 Layer: Poplar
Grade	Rustic
Pack Size	2.508 m ²
Pack Contents	Random Length Boards
Joint Type	Tongue & Groove
Edge Profile	Bevel Edged on 4 sides

Grading: Rustic

This floor may contain varying amounts of live and dead filled knots. In addition, the floor will contain Heartwood and Sapwood, offering a wider range of colour variation, and Expert Checks can be expected (cracks along the growth ring). The colour of the filler used on this floor is intended to complement the natural structure of the wood, and such may contrast the surrounding timber, as can be seen in knots. This may vary from batch to batch.

Technical Information	
Origin	China
UKTR/ UK Timber Regulation	Compliant
FSC* Certification	Certification is available for project enquiries
PEFC* Certification	Not available with this product
Janka Hardness	Oak 1360 lbf (6000N)
Slip Resistance	EN 14231 (Test Result 80/46 PTV)
European Reaction to Fire Classification	EN 13501-1 (test result Dfl-s1)
Release of Formaldehyde	EN 717-1 (Test result E1)
Thermal Conductivity	EN 12524 (Test result: 0.143 W / mK)
Installation Methods	
Fully Bonded	Yes*
Secret Nailed	No
Floated on Underlay	Yes*
V4Magnetic®	Yes**
Over Underfloor Heating	Yes*

^{*} Subject to correctly prepared and compatible subfloor in conjunction with correct installation and usage.

Installation - Important Guidance:

All V4 floors must be installed by an experienced and fully competent flooring installer who have the necessary skills to complete each installation in line with the BS8201:2011 standard. The responsibility for inspection the of goods lies with the installer, and it is their duty to notify V4 of any potential concerns prior to installation. Installation of your V4 floor is considered acceptance of goods.

For full guides visit v4.co.uk/support or scan the Product QR code below.

Post Installation - Important Note:

DO NOT COVER AN INSTALLED WOOD FLOOR WITH A NON-BREATHABLE COVERING FOR LONGER THAN 1 WEEK. Prolonged covering may create a microclimate which can damage the protective top layer. Underfloor heating will greatly magnify the effect.

Scan QR code for more product info:



- Installation Guides
- Underfloor Heating Advice
- Maintenance Schedule
- Floorcare Advice
- Product Images
- Room Visualiser
- Order FREE samples

Explore our full range of flooring solutions at v4.co.uk

^{**} Find out more at www.v4.co.uk/v4magnetic